

INREACH: USER MANUAL

[Home](#) → InReach: User manual

InReach is a satellite communicator that allows input, transmission and reception of the messages, track points and SOS signals directly from the device, as well as built-in navigation with Way Points and routing.



User manual:

1. POWER - Device switch-on.

Press and hold the button pressed for 5 seconds until the indicator above the button starts flashing frequently.

Release the button - the indicator shall flash with the frequency 1 impulse per second.

2. Tracking — Tracking switch-on

Press and hold the button pressed for 5 seconds until the indicator above the button starts flashing frequently.

Release the button - the indicator shall flash with the frequency 1 impulse per second. Your device starts sending the impulses to the monitoring server.

3. OK message - sends the OK message from the team when it withdraws from the competition due to technical reasons.

Press and hold the button pressed for 5 seconds until the indicator switches on.

Release the button - the indicator shall flash with the frequency 1 impulse per second. The headquarters of the competition will receive the OK message.

4. SOS message - sends SOS signal to request urgent medical help to the competitor.

Push aside the SOS button fuse - press and hold the button pressed for 5 seconds until the indicator above switches on. Release the button - the indicator shall flash with the frequency 1 impulse per second. The headquarters of the competition will receive the SOS message and GPS coordinates of the location.

Shall be pressed only to call urgent medical help for the competitor.